


RAINDROPS WON'T BE FALLING ON YOUR HEAD WITH



DripX™ is a factory-applied material that controls condensation. When temperature and humidity conditions reach the dew point, moisture condenses on the underside of a metal roof and forms drops of water, which can rain down on anything below it causing serious damage and irritation.

Roof panels with **DripX™** applied have a medium for trapping this moisture in the pockets formed in the membrane material. **DripX™** holds moisture until conditions go back above the dew point, and it is released back into the air in the form of normal humidity.

BENEFITS TO CONTRACTORS

Saves time - cuts out one step in the building process by replacing the need for vapor barrier.

- **Avoid delays** from windy conditions making it difficult to install vapor barrier
- More efficiency = more jobs = **more \$\$\$** and meeting more deadlines

Reduces liability by requiring less labor at elevated levels

TECHNICAL DATA

- **UL 723 Approved** - Meets flame spread and smoke generation requirements for insurance
- **Anti-microbial** material (polyester and rubber) = NO mold or mildew issues
- Holds up to 10 times its weight in water (more than 1 qt. per 10 square ft.)
- No R value (insulating property)
- **Extremely resistant** to tearing and deterioration
- Adhesion improves with age
- **Durable** - This material has been in virtually every climate condition on every continent and has been marketed for 15 years.
- Appropriate for use in animal confinement.
- Helps with **noise reduction** - up to 20% of rain noise and reflective noise
- Eaves should be sealed (please refer to panel preparation instructions on the reverse side)
- **Will not** void your substrate warranty
- **Easy to clean** with hose or pressure washer



**CONTACT YOUR SALESPERSON FOR DETAILS
REGARDING PRICING AND AVAILABILITY.**

Lowell, AR
800-356-2733

Michigan City, IN
800-638-2565

Cedar Hill, TX
800-210-8305

Mount Airy, NC
877-813-2111

Jasper, AL
866-270-6608



IMPORTANT: READ BEFORE INSTALLATION

When installing panels with **DripX™** Condensation Control, it is critical that panels and/or trim are properly prepared at key junctures -- such as eaves, endlaps and ridge caps -- to prevent moisture from wicking from the outside.

HOW TO PROPERLY PREP PANELS AND TRIM:

For all points of exposure to outside environment, a recommended length of the panel should be prepared, such as:

- Eave overhang (overhang + 1")*
- Panel to panel endlaps (length of lap minus ¼")
recommended to avoid endlaps and run panels continuously from eave to ridge
- Ridge cap laps (length of lap minus ¼")

1. Lay/stack panels with **DripX™** Condensation Control material facing up and recommended length of each panel exposed.
2. Using a heat gun set at 1200°F, move the gun along the exposed end portion of each panel, heating/fusing the fibers of the **DripX™**.
 - Hold the heat gun approximately 1" away from the **DripX™** material.
 - Keep the heat gun in constant motion to avoid overheating one spot, potentially damaging the panel's finish.
 - Do not completely melt the **DripX™** material.
 - If at lap, do not extend fusing past the lap.
3. Allow panels to cool.
4. Install panels as normal.

**Eaves may be prepared after installation of panels.*

Failure to properly prepare panels may result in the DripX™ material attracting water from outside, resulting in possible leaks, mold and/or mildew -- ultimately voiding your panel warranty.